






BodyBilt®



Sola LT
Instructions



Sola LT Instructions



Armrest Height Lever

Lift and hold lever to adjust armrest height. Release lever to set.

Seat Height Lever

Lift and hold lever to adjust seat height. Release lever to set.

Back Angle Lever

Lift and hold lever to adjust back angle. Release lever to set.



Lumbar Support

Slide lumbar pad up or down to adjust.

Seat Tilt Lever

Lift lever to adjust seat angle. Push lever down to set.

Seat Depth Lever

Lift and hold lever to slide seat. Release lever to set.

Seat Tilt Tension Knob

Turn knob clockwise to tighten and counter clockwise to loosen.

www.BodyBilt.com

Weight rating: 250lbs

BodyBilt®